



H2002YG Instruction manual

CREATE FOR GAME

Trouble shooting

If the microphone doesn't work, please follow below steps to check if everything is all set.

1. Plug the detachable microphone into the microphone port in the correct direction till you hear a click sound.



2. In the Windows system, you can also adjust the default audio output device through the "Sound" settings to ensure that both the front and rear panels can be correctly recognized and used.

Headphone Specification

Speaker: 95mm

Lithium battery: 600mAh

Impedance: 32±15%Ω

Sensitivity: 86±3dB

Frequency response: 20Hz to 20KHz

Microphone: Ø6.0x2.7mm

Microphone sensitivity: -42±3dB

Wireless distance: 10m

Plug: 2.4GHz+ Wireless+ Type-C Audio cable+ 3.5mm Audio cable

Charging time: 2.5H

Charging method: (Type-C) USB 5V


Low latency 28MS

Size: 88*138*188mm

product weight: 257g

Continuity Play: 2.4G: 19H: Wireless: 22H

Function Image



01

Operation Guide

Wired mode(Type-c Audio cable)

1) Plug in the TYPE-C cable, and long press the power switch to turn on the headphone. At this time, the headphone is in wired mode (Note: In wireless or 2.4G mode, plugging in the TYPE-C cable will directly switch to wired mode. Unplugging the cable will automatically switch to wireless or 2.4G mode)

2) Short, Long press the volume +/- for volume adjustment. Double click volume +/- for up/down song adjustment.

3) The microphone is turned on by default. To turn off the microphone, press the microphone key once (voice prompt is "beep beep"). To turn on the microphone, press the microphone key again (voice prompt is "beep")

4) The headset defaults to stereo sound. Short press 7.1 key to switch to virtual 7.1 channel (voice prompt is "beep beep"), press again to switch back to stereo (voice prompt is "beep").

Wired mode(3.5mm Audio cable)

1) Plug and play: Connecting the headphone to a music player with the provided dual 3.5mm audio cable, the headphone can be used as wired headphone without starting.

2) In this mode, you can't use any function of the headphone, including pause playback, volume adjustment, microphone and so on.

2.4G mode

1. How to match

1) Turn off the headphones and remove the transmitter.

2) Press the power button to turn on the headphone, and the indicator lights up and flashes slowly. Then double-click the power button switch to "Gaming Mode".

3) Turn on the 2.4G receiver (plug the receiver into PC, PS4 and other devices)

4) The headphone and receiver are automatically paired and the indicator lights up (for headphone that have already been paired).

02

HAVIT

2. Operating instructions

1) Connect the receiver to PC/PS4 or other devices, the indicator lights up and flashes.

2) Turn on the headphone, it will automatically pair to the transmitter. The indicator will be always on after the pairing is successful.

3) Short, Long press the volume +/- for volume adjustment. Double click volume +/- for up/down song adjustment.

4) The microphone is turned on by default. To turn off the microphone, press the microphone key once (voice prompt is "beep beep"). To turn on the microphone, press the microphone key again (voice prompt is "beep")

5) The headset defaults to stereo sound. Short press 7.1 key to switch to virtual 7.1 channel (voice prompt is "beep beep"), press again to switch back to stereo (voice prompt is "beep"). (See 2.4G UI below for specific operations)

6) Low Power Mode: When the battery power supply voltage is less than 3.30V, the sound will beep one time every one minute.

7) Power off mode: when the battery power supply voltage is less than 3.25V or when there is no sound source connection the with 10 minutes, the headset will turn off.

	Bottom/Function/Light	Function instruction	Operation	Prompt/Voice
2.4G UI	7.1 button	7.1 Sound effects	Click the 7.1 button	Default 2.0 mode, hear two beeps for 7.1 mode, hear one beep for 2.0 mode
	Volume+	Volume+	Click	One beep at maximum volume
			Long click press	
	Volume-	Volume-	Click	Minimum volume beeps once
			Long click press	
	Mic on/off	Mic on/off	Short click	Default is on, the transmitter indicator is always on, off the microphone indicator is off
			Double click	
	Power switch	2.4G mode and Wireless mode switching	Double-click the Power button	2.4G mode: "Gaming Mode", "power on", power off: "Power off"
			ON: Long press 1.5s	
			OFF: Long press 3s	
Play/Pause				

03

Wireless mode

1) Turn on the headphone, double-click the power button switch to wireless mode, and you can hear the voice prompt: "Wireless mode". When the headphone enter the pairing mode, the indicator will flash and voice prompt is "power on".

2) This headphone is compatible with most of smart phones and other devices that support wireless headphone protocol.

3) Turn on your phone and enter wireless mode. Then search "H2002YG" for pairing.

4) Click "H2002YG" to pair. After pairing is successful, the voice prompt is "connected", and the indicator will be always on. (If the device have been paired before, the headphone will automatically connect with it under Wireless mode.)

Key function

Answer an incoming call

Short press the power button to answer the incoming call.

Tip: As some mobile phones answer calls through their own receivers by default, please refer to your mobile phone instructions and set them on your mobile phone.

End current call

Short press the power button to end the current call.

Refuse to answer the phone

When there is an incoming call, press the power button for 1.5 seconds.

Play music

1) Play/Pause: short press the power button.

2) Previous song: Double-click "Volume+" for the previous song.

3) Next song: Double-click "Volume-" for the next song.

4) Volume+: Short/long press "Volume+" to increase the volume.

5) Volume-: Short/long press "Volume-" to decrease the volume. (See the wireless UI below for details.)

04

	Bottom/Function/Light	Function instruction	Operation	Prompt/Voice
Wireless UI	7.1 button	7.1 Sound effects	Click the 7.1 button	Default 2.0 mode, hear two beeps for 7.1 mode, hear one beep for 2.0 mode
	Volume+	Volume+	Click	One beep at maximum volume
			Long click press	
	Volume-	Volume-	Click	Minimum volume beeps once
			Long click press	
	Mic on/off	Mic on/off	Short click	Default is on, the transmitter indicator is always on, off the microphone indicator is off
			Double click	
	Power switch	2.4G mode and Wireless mode switching	Double-click the Power button	Wireless mode beep: Wireless mode, power on, waiting for pairing; Pairing
			ON: Long press 1.5s	Wireless mode: "Wireless mode", "power on", "waiting for pairing"
			OFF: Long press 3s	"Pairing", "Power off: power off"
Play/Pause			Short click	
		Answering up phone	Short click	
		Decline a call	Long press 1.5s	

Warnings

• Please follow the instruction to operate

• PLS charge the headphone with input power below 3.3V, in order to protect the battery;

• Please store or use the headphone in a normal temperature environment.

• PLS keep the headphone from heat source, such as radiators, hot air regulators, stoves, or other heat generating instruments. As it is not anti-high temperature.

• Don't jam the ports of the headphone, such as charger port, LED port and microphone etc.

• In order to protect your hearing and extend the headphone service life, it is not recommended to adjust the volume to the maximum level for a long time.

• Whatever reasons damage the headphone, please free to contact our after-sales staff in time rather than repair by yourself. Otherwise, you will accept without after-sales service.

05

Cód. de Homologação 06014-24-12374



ESTE EQUIPAMENTO NÃO TEM DIREITO À PROTEÇÃO CONTRA INTERFERÊNCIA PREJUDICIAL E NÃO PODE CAUSAR INTERFERÊNCIA EM SISTEMAS DEVIDAMENTE AUTORIZADOS.

06